

Jamberly Group
Louisville, KY 40245 USA

11/18 Model: HB 6000 Series

Patent Pending

90 Days Limited Warranty

If, during the first 90 days after consumer purchase of the product, under normal and non-commercial use, it fails while owned by the original purchaser due to quality of materials used or workmanship, Jamberly Group will replace or repair at Jamberly's option.

Made in China

Owner's Manual

ciao! baby®



the-go-anywhere-booster

ciao! baby PUG

Model: HB 6000 Series

 **WARNING**

Children have suffered **head injuries**, including skull fractures, **after falling** with or from booster seats.

- Check that booster seat is **securely attached** to adult chair before each use.
- **Always use restraints** until child is able to get in and out of booster seat without help. Adjust to **fit snugly**.

Note—The restraint statement is not required for booster seats age graded only for children 36 months and older.

- **Never** allow child to **push away from table**.
- **Never lift** and **carry** child in booster seat.
- **Stay near** and **watch** your child during use.

 **WARNING**

Prevent serious injury or death. Do not use in motor vehicle

 **WARNING**

Until child is able to get in and out of the booster seat without help (about 2 1/2 years old), the child should be secured in the booster seat at all times by the restraining system. The tray is not designed to hold the child in the chair.

Jamberly Group Louisville, KY 40245 USA

WARNING:

Prevent serious injury or death from falls or sliding out. Failure to follow these warnings could result in serious injury or death.




- Always secure child in restraints.
- Never leave child unattended. Always keep child in view when in high chair.
- Do not use on uneven surfaces.
- Keep seat and table surface clean and dry to prevent seat from slipping.
- Use only for a child capable of sitting upright unassisted.
- Do not allow other children or animals to play near or walk under chair while in use.
- Use only for children up to 35 pounds.
- Before removing child from chair, be sure child's legs are free from restraints.
- Always ensure all hazards such as electric appliances, sharp objects, and hot liquids are kept out of reach of child in the chair.
- Do not hang objects from the chair.
- Do not use the chair for more than one child at a time.
- The tray is not designed to hold the child in the chair. Always use the restraining system.

PUG - INSTRUCTIONS TO ATTACH TO A CHAIR

Minimum seat dimensions of chair to be attached to is 15 inches x 15 inches, minimum backrest height is 17 inches.

Securing seat to a chair:

Attach one strap to the buckle on the back leg, wrap around back of dining chair, attach other end of strap to the other side buckle on the back leg. Secure by pulling both sides to tighten. Attach the second strap to the side cross bar buckle, wrap under the dining chair, attach to the buckle on the other side cross bar. Secure by pulling both sides to tighten.



ASSEMBLY INSTRUCTIONS:

READ ALL INSTRUCTIONS BEFORE ASSEMBLY AND USE OF CHAIR. KEEP INSTRUCTIONS FOR FUTURE USE.


1. Remove chair from carrying bag.
2. Unfold chair and firmly press down until fully open.
3. Secure child in lap belt and shoulder harness. Adjust both so that the belts are firmly secured around the child's waist and shoulders.

CLOSING THE CHAIR


1. Before attempting to close the chair, remove child.
2. Lift at the tray corners and fold chair.
3. Store in carrying bag.

CARE AND MAINTENANCE


Always check the strength of the fabric and the strength of the stitching each time the fabric is washed. To clean wipe surface with a damp cloth or sponge. A mild liquid soap may be used. Do not use bleach or any solvents. Allow to dry completely before storing in bag. Outside storage is not recommended. Store in dry location.



Lift child into or out of seat safely.
TIP: Stand behind child when taking in and out of chair.



Tighten each shoulder strap so child is secure.



Buckle child safely onto chair. Tighten waist and shoulder straps to secure before use.

TIP: If tray slants toward child, locate the grommets at the back of the tray arms and slide up to level out tray.